

### PRIOR TO INSTALLATION:

Check to ensure that the installation will conform with all applicable Federal, State and Local Building Codes & Regulations.

1. Drill a 4" hole in your subfloor.



2. Measure the distance from the inside of the P-trap to the top of the floor. (P-Trap not included)





3. Cut the ABS 1 1/2" pipe 3" shorter than the distance between the floor and the P-trap.




4. Apply ABS glue to the outside of the ABS 1 1/2" pipe and to the inside of the P-trap.



5. Apply ABS glue to the outside of the ABS 1 1/2" pipe and to the black plastic inside the bottom of the Drop-In Drain insert.



6. Slide the Drop-In Drain on the ABS 1 1/2" pipe making sure it sits flat on the floor.



7. Insert the Drop-In Drain cap firmly into the Drop-In Drain for testing.



8. Secure the Drop-In Drain to the subfloor with screws or cement.



9. Install your flooring surface around the outside of the Drop-In Drain. Do Not Cover Drain.



10. Remove the Drop-In Drain cap with a channel lock plier after pressure test has been completed.




11. Apply provided lubricant inside black plastic tubing of the Drop-In Drain.



12. Affix the appropriate tailpiece to the waste drain. Ensure the measurement between the base of the Drop-In Drain and the P-trap will accommodate the tailpiece.



13. Apply provided lubricant halfway up the tailpiece and position the bathtub and tailpiece in line with the Drop-In Drain.



14. With caution, slowly insert the bathtub with the tailpiece into the Drop-In Drain.

